



Assembly Instruction

Item No: TV cabinet (Drawer)



NO	list of parts	Qty	NO	Hardware/Components list	Qty
①	Bottom board	1	A	3in1 connector	26
②	MI-Side board	1	B	Wood Nog	12
③	Back board	1	C	Fixed parts	8
④	Back board	1	D	Drawer Slide	2
⑤	Side board	2	E	Screw Scr	4
⑥	Top board	1	F	Handle	2
⑦	Drawer	2	G	Handle Screw	4
			H	Screw Scr	28
			I	Screw Scr	4
			J	Backplane buckle	8
			K	Legs	5
			L	Screw Scr	20

